



**Instructions**

Emergency light has to be installed center of the left wall of RSC measuring 25cm below from the ceiling.  
Electrical wiring to the unit will be concealed inside the wall.  
Power plug should be installed at the back wall and easily accessible for testing.